



MODEL: GWH09MA-K3NNA3F GWH09MA-K3NNA3E GWH09MA-K3NNC5A GWH09MA-K3NNC8A (Refrigerant R410A)

GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI


	Summary and features	1
Part 1	Safety Precautions	2
Part 2	Specifications	3
	2.1 Unit Specifications	9
Part 3	Construction Views	
	3.2 Outdoor Unit	10
Part 4	Refrigerant System Diagram	11
Part 5	Schematic Diagram	12
	5.1 5.1 Electrical Data	12
Part 6	Function and Control	18
	6.1 Remote Control Operations	
Part 7	Installation Manual	28
	7.1 Notices for installation	28
	7.2 Installation diagram	
	7.3 Install indoor unit	
	7.4 Install of Quick Connector	
	7.6 Check after Installation and Operation Test	
	7.7 Installation and Maintenance of Healthy Filter	38

Part 8	Exploded Views and Parts List	39
	8.1 Indoor Unit	39
	8.2 Outdoor Unit	47
Part 9	Troubleshooting	53
	9.1 Mlafunction Code	53
	9.2 How to Check simply the main part	54
Part10	Removal Procedure	58
	10.1 Removal Procedure of Indoor Unit	58
	10.2 Removal Procedure of Outdoor Unit	66
	10.3 Removal Procedure of Outdoor Unit(Quick Connector)	70


Summary and features

Indoor Unit

GWH09MA-K3NNA3F/I GWH09MA-K3NNA3E/I



GWH09MA-K3NNC5A/I




GWH09MA-K3NNC8A/I



Outdoor Unit

GWH09MA-K3NNA3A/O GWH09MA-K3NNA3E/O GWH09MA-K3NNA3F/O



Remote control window



1. Safety Precautions

Installing, starting up, and servicing air conditioner can be hazardous due to system pressure, electrical components, and equipment location, etc.

Only trained, qualified installers and service personnel are allowed to install, start-up, and service this equipment. Untrained personnel can perform basic maintenance functions such as cleaning coils. All other operations should be performed by trained service personnel.

When handling the equipment, observe precautions in the manual and on tags, stickers, and labels attached to the equipment. Follow all safety codes. Wear safety glasses and work gloves. Keep quenching cloth and fire extinguisher nearby

Read the instructions thoroughly and follow all warnings or cautions in literature and attached to the unit. Consult local building codes and current editions of national as well as local electrical codes.

Recognize the following safety information:



Warning Incorrect handling could result in personal injury or death.



Incorrect handling may result in minor injury, or damage to product or property.

- Make sure the outdoor unit is installed on a stable, level surface with no accumulation of snow, leaves, or trash beside.
- Make sure the ceiling/wall is strong enough to bear the weight of the unit.
- Make sure the noise of the outdoor unit does not disturb neighbors.
- Follow all the installation instructions to minimize the risk of damage from earthquakes, typhoons or strong winds.
- Avoid contact between refrigerant and fire as it generates poisonous gas.
- Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture and other hazards.
- Make sure no refrigerant gas is leaking out when installation is completed.
- Should there be refrigerant leakage, the density of refrigerant in the air shall in no way exceed its limited value, or it may lead to explosion.
- Keep your fingers and clothing away from any moving
- Clear the site after installation. Make sure no foreign objects are left in the unit.
- Always ensure effective grounding for the unit.



Warning

All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.

- Before installing, modifying, or servicing system, main electrical disconnect switch must be in the OFF position. There may be more than 1 disconnect switch. Lock out and tag switch with a suitable warning label.
- Never supply power to the unit unless all wiring and tubing are completed, reconnected and checked.
- This system adopts highly dangerous electrical voltage. Incorrect connection or inadequate grounding can cause personal injury or death. Stick to the wiring diagram and all the instructions when wiring.
- Have the unit adequately grounded in accordance with local electrical codes.
- Have all wiring connected tightly. Loose connection may lead to overheating and a possible fire hazard.

All installation or repair work shall be performed by your dealer or a specialized subcontractor as there is the risk of fire, electric shock, explosion or injury.



Caution

- Never install the unit in a place where a combustible gas might leak, or it may lead to fire or explosion.
- Make a proper provision against noise when the unit is installed at a telecommunication center or hospital.
- Provide an electric leak breaker when it is installed in a watery place.
- Never wash the unit with water.
- Handle unit transportation with care. The unit should not be carried by only one person if it is more than 20kg.
- Never touch the heat exchanger fins with bare hands.
- Never touch the compressor or refrigerant piping without wearing glove.
- Do not have the unit operate without air filter.
- Should any emergency occur, stop the unit and disconnect the power immediately.
- Properly insulate any tubing running inside the room to prevent the water from damaging the wall.

2.Specifications

2.1 Unit Specifications

Model			GWH09MA-K3NNC8A GWH09MA-K3NNC5A		
Product C	Code		CA19200010	CA17900040	
_	Rated Voltage	V~	220-	-240	
Power Supply	Rated Frequency	Hz	5	0	
Phases			1		
Power Su	upply Mode		Ind	oor	
Cooling C	Capacity	W	26	00	
Heating C	Capacity	W	28	00	
Cooling F	Power Input	W	80	9	
Heating F	Power Input	W	77	75	
Cooling F	Power Current	Α	3.	7	
Heating F	Power Current	Α	3.	5	
Rated Inp	put	W	1120/	1020	
Rated Cu	rrent	Α	5/4	1.5	
Air Flow \	Volume(SH/H/M/L/SL)	m ³ /h	500	l- - -	
Dehumidi	ifying Volume	L/h	0.	8	
EER		W/W	3.2	21	
COP		W/W	3.0	31	
SEER		W/W	1		
HSPF		W/W	1		
Application	olication Area m ²		12-	-18	
	Model of indoor unit		GWH09MA-K3NNC8A/I	GWH09MA-K3NNC5A/I	
	Fan Type		Cross	s-flow	
	Diameter Length(DXL)	mm	Ф85)	K596	
	Fan Motor Cooling Speed(SH/H/M/L/SL)	r/min	1260/1050	/920/730/-	
	Fan Motor Heating Speed(SH/H/M/L/SL)	r/min	1320/1200/	1100/950/-	
	Output of Fan Motor	W	1	0	
	Fan Motor RLA	Α	0.	.1	
	Fan Motor Capacitor	μF	1		
	Input of Heater	W	I	1	
	Evaporator Form		Aluminum Fin	-copper Tube	
Indoor	Pipe Diameter	mm	Ф	7	
Unit	Row-fin Gap	mm	2-1	1.5	
	Coil Length (LXDXW)	mm	581X25	.4X264	
	Swing Motor Model		MP2	4AA	
	Output of Swing Motor	W	1.	5	
	Fuse	Α	PCB :	3.15A	
	Sound Pressure Level (SH/H/M/L/SL)	dB (A)	39/36/33/30/-	39/36/33/30/-	
	Sound Power Level (SH/H/M/L/SL)	dB (A)	50/48/45/42/-	50/48/45/42/-	
	Dimension (WXHXD)	mm	790X26	65X177	
	Dimension of Carton Box (L/W/H)	mm	867X24	45X340	
	Dimension of Package(L/W/H)	mm	870X24	18X355	
	Net Weight	kg	Ç)	
	Gross Weight	kg	1	2	

	Model of Outdoor Unit		GWH09MA-K3NNA3A/O
	Compressor Manufacturer/Trademark		ZHUHAI LANDA COMPRESSOR CO. LTD. /GREE
	Compressor Model		QXA-B102uC130
	Compressor Oil		PVE(DN HERMITIC FVC 68D)
	Compressor Type		Rotary
	L.R.A.	Α	18
	Compressor RLA	А	3.9
	Compressor Power Input	W	858
	Overload Protector		B210-150-241H
	Throttling Method		Capillary
	Operation Temp	$^{\circ}$	16~30
	Ambient Temp (Cooling)	$^{\circ}$	18~43
	Ambient Temp (Heating)	$^{\circ}$	-7∼24
	Condenser Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7
	Rows-fin Gap	mm	1-1.4
	Coil Length (LXDXW)	mm	741X495.3X12.7
	Fan Motor Speed	rpm	850
	Output of Fan Motor	W	30
Outdoor	Fan Motor RLA	Α	0.23
Unit	Fan Motor Capacitor	μF	2
	Air Flow Volume of Outdoor Unit	m³/h	1800
	Fan Type		Axial-flow
	Fan Diameter	mm	Ф400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IP24
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	3.8
	Permissible Excessive Operating Pressure for the Suction Side	MPa	1.2
	Sound Pressure Level (H/M/L)	dB (A)	50/-/-
	Sound Power Level (H/M/L)	dB (A)	60/-/-
	Dimension (WXHXD)	mm	848X540X320
	Dimension of Carton Box (L/W/H)	mm	875X357X565
	Dimension of Package(L/W/H)	mm	878X360X580
	Net Weight	kg	26
	Gross Weight	kg	30
	Refrigerant		R410A
	Refrigerant Charge	kg	0.75
	Length	m	4
	Gas Additional Charge	g/m	20
	Outer Diameter Liquid Pipe	mm	Ф6
n Pipe	Outer Diameter Gas Pipe	mm	Ф9.52
	Max Distance Height	m	10
	Max Distance Length	m	20

The above data is subject to change without notice. Please refer to the nameplate of the unit.

Model			GWH09MA-K3NNA3F
Product Code			CA17100680
_	Rated Voltage	V~	220-240
Power Supply	Rated Frequency	Hz	50
Supply	Phases		1
Power Su	pply Mode		Indoor
Cooling C	apacity	W	2600
Heating C	apacity	W	2800
Cooling P	ower Input	W	809
Heating P	ower Input	W	775
Cooling P	ower Current	А	3.59
Heating P	ower Current	А	3.44
Rated Inp	ut	W	1120
Rated Cu	rrent	А	4.97
Air Flow \	/olume(SH/H/M/L/SL)	m ³ /h	500/-/-/-
Dehumidi	fying Volume	L/h	0.8
EER		W/W	3.21
COP		W/W	3.61
SEER		W/W	1
HSPF		W/W	1
Application Area		m ²	12-18
	Model of indoor unit		GWH09MA-K3NNA3F/I
	Fan Type		Cross-flow
	Diameter Length(DXL)	mm	Ф85Х596
	Fan Motor Cooling Speed(SH/H/M/L/SL)	r/min	1260/1050/920/730/-
	Fan Motor Heating Speed(SH/H/M/L/SL)	r/min	1320/1200/1100/950/-
	Output of Fan Motor	W	10
	Fan Motor RLA	А	0.13
	Fan Motor Capacitor	μF	1
	Input of Heater	W	1
	Evaporator Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7
Indoor Unit	Row-fin Gap	mm	2-1.5
Offic	Coil Length (LXDXW)	mm	589X25.4X266.7
	Swing Motor Model		MP24AA
	Output of Swing Motor	W	1.5W
	Fuse	А	PCB 3.15A
	Sound Pressure Level (SH/H/M/L/SL)	dB (A)	40/37/35/32/-
	Sound Power Level (SH/H/M/L/SL)	dB (A)	49/47/45/42/-
	Dimension (WXHXD)	mm	790X265X170
	Dimension of Carton Box (L/W/H)	mm	870X248X355
	Dimension of Package(L/W/H)	mm	873X251X370
	Net Weight	kg	9
	Gross Weight	kg	12

	Model of Outdoor Unit		GWH09MA-K3NNA3F/O
	Compressor Manufacturer/Trademark		GREE
	Compressor Model		QXA-B102uC130
	Compressor Oil		PVE(DN HERMITIC FVC 68D)
	Compressor Type		Rotary
	L.R.A.	Α	18
	Compressor RLA	Α	4±5%
	Compressor Power Input	W	858±5%
	Overload Protector		B210-150-241H
	Throttling Method		Capillary
	Operation Temp	$^{\circ}\! \mathbb{C}$	16~30
	Ambient Temp (Cooling)	$^{\circ}\! \mathbb{C}$	18~43
	Ambient Temp (Heating)	°C	-7~2 4
	Condenser Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7
	Rows-fin Gap	mm	1-1.4
	Coil Length (LXDXW)	mm	780.45X12.7X495.3
	Fan Motor Speed	rpm	800
	Output of Fan Motor	W	30
Outdoor	Fan Motor RLA	A	0.37
Outdoor Unit	Fan Motor Capacitor	μF	2
0	Air Flow Volume of Outdoor Unit	m ³ /h	1800
	Fan Type	111 711	Cross-flow
	Fan Diameter	mm	400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		
	Moisture Protection		IP24
	Permissible Excessive Operating Pressure for the Discharge Side	MPa	3.8
	Permissible Excessive Operating Pressure for the Suction Side	MPa	1.2
	Sound Pressure Level (H/M/L)	dB (A)	50
	Sound Power Level (H/M/L)	dB (A)	60
	Dimension (WXHXD)	mm	848X540X320
	Dimension of Carton Box (L/W/H)	mm	878X360X580
	Dimension of Package(L/W/H)	mm	881X363X605
	Net Weight	kg	29
	Gross Weight	kg	33
	Refrigerant		R410A
	Refrigerant Charge	kg	0.75
	Length	m	4
	Gas Additional Charge	g/m	20
Connectio	Outer Diameter Liquid Pipe	mm	Ф6
n Pipe	Outer Diameter Gas Pipe	mm	Ф9.52
	Max Distance Height	m	10
	Max Distance Length	m	15


The above data is subject to change without notice. Please refer to the nameplate of the unit.


Model			GWH09MA-K3NNA3E
Product Code			CA17100800
_	Rated Voltage	V~	220-240
Power Supply	Rated Frequency	Hz	50
Supply	Phases		1
Power Su	pply Mode		Indoor
Cooling C	Capacity	W	2680
Heating C	Capacity	W	2880
Cooling P	ower Input	W	834
Heating P	Power Input	W	797
Cooling P	ower Current	А	3.70
Heating P	ower Current	А	3.54
Rated Inp	ut	W	1120
Rated Cu	rrent	А	4.97
Air Flow \	/olume(SH/H/M/L/SL)	m ³ /h	500 /-/-/-
Dehumidi	fying Volume	L/h	0.8
EER		W/W	3.21
COP		W/W	3.61
SEER	SEER		1
HSPF	HSPF		1
Application Area		m ²	12-18
	Model of indoor unit		GWH09MA-K3NNA3E/I
	Fan Type		Cross-flow
	Diameter Length(DXL)	mm	Ф85Х596
	Fan Motor Cooling Speed(SH/H/M/L/SL)	r/min	1260/1050/920/730/-
	Fan Motor Heating Speed(SH/H/M/L/SL)	r/min	1320/1200/1100/950/-
	Output of Fan Motor	W	10
	Fan Motor RLA	А	0.13
	Fan Motor Capacitor	μF	1
	Input of Heater	W	I
	Evaporator Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7
Indoor Unit	Row-fin Gap	mm	2-1.5
Offic	Coil Length (LXDXW)	mm	589X25.4X266.7
	Swing Motor Model		MP24AA
	Output of Swing Motor	W	1.5W
	Fuse	A	PCB 3.15A Transformer 0.2A
	Sound Pressure Level(SH/H/M/L/SL)	dB (A)	39/37/35/32/-
	Sound Power Level(SH/H/M/L/SL)	dB (A)	49/47/45/42/-
	Dimension (WXHXD)	mm	790X265X170
	Dimension of Carton Box (L/W/H)	mm	1017X325X352
	Dimension of Package(L/W/H)	mm	1020X328X367
	Net Weight	kg	13.5
	Gross Weight	kg	18

	Model of Outdoor Unit		GWH09MA-K3NNA3E/O
	Compressor Manufacturer/Trademark		ZHUHAI LANDA COMPRESSOR CO. LTD. /GREE
	Compressor Model		QXA-B102uC130
	Compressor Oil		PVE(DN HERMITIC FVC 68D)
	Compressor Type		Rotary
	L.R.A	Α	18
	Compressor RLA	Α	4±5%
	Compressor Power Input	W	858±5%
	Overload Protector		B210-150-241H
	Throttling Method		Capillary
	Operation Temp	$^{\circ}$	16~30
	Ambient Temp (Cooling)	$^{\circ}$	18~43
	Ambient Temp (Heating)	$^{\circ}$	-7∼24
	Condenser Form		Aluminum Fin-copper Tube
	Pipe Diameter	mm	Ф7
	Rows-fin Gap	mm	1-1.4
	Coil Length (LXDXW)	mm	780.45X12.7X495.3
	Fan Motor Speed	rpm	800
	Output of Fan Motor	W	30
Outdoor	Fan Motor RLA	Α	0.37
Unit	Fan Motor Capacitor	μF	2
J	Air Flow Volume of Outdoor Unit	m ³ /h	1800
	Fan Type		Cross-flow
	Fan Diameter	mm	400
	Defrosting Method		Automatic Defrosting
	Climate Type		T1
	Isolation		I
	Moisture Protection		IP24
	Permissible Excessive Operating Pressure for the	MD-	2.0
	Discharge Side	MPa	3.8
	Permissible Excessive Operating Pressure for the Suction Side	MPa	1.2
	Sound Pressure Level (H/M/L)	dB (A)	50
	Sound Power Level (H/M/L)	dB (A)	60
	Dimension (WXHXD)	mm	848X540X320
	Dimension of Carton Box (L/W/H)	mm	878X360X580
	Dimension of Package(L/W/H)	mm	881X363X595
	Net Weight	kg	29
	Gross Weight	kg	33
	Refrigerant	''a	R410A
	Refrigerant Charge	kg	0.70
	Length	m	5
	Gas Additional Charge	g/m	1
Connecti	Outer Diameter Liquid Pipe	mm	,
on Pipe	Outer Diameter Gas Pipe	mm	,
	Max Distance Height	m	,
	Max Distance Length	m	1
	MAX DISTANCE CONSTITUTE	111	,

The above data is subject to change without notice. Please refer to the nameplate of the unit.

2.2 Capacity Variation Ratio According to Temperature





2.3 Operation Data

Cooling

Temperature	condition (°C)	Model name	Standard pressure	Heat exchang	ger pipe temp	Indoor fan	Outdoor fan	Compresso r revolution
Indoor	Outdoor	Woder Hairie	P (MPa)	T1 (°C)	T2 (°C)	mode	mode	(rps)
27/19	35/24	9K	0.99~1.19	10.2 to 13.4	79.6 to 37.9	1260	830±20	1
27/19	35/24	12K	0.48~0.56	in:8 to 11 out:11 to 14	in:75 to 85 out:37 to 43	1260	850	/

Heating

Temperature	condition (°C)	Model name	Standard pressure	Heat exchang	ger pipe temp	Indoor fan	Outdoor fan	Compresso r revolution
Indoor	Outdoor	Woder Hairie	P (MPa)	T1 (°C)	T2 (°C)	mode	mode	(rps)
20/-	7/6	9K	2.38~2.58	80.1 to 35.5	7.5 to 5.3	1320	830±20	1
20/-	7/6	12K	1.55~1.75	in:75 to 85 out:37 to 43	in:1 to 3 out:2 to 5	1280	850	1

P: gas valve outlet pressure

T1: outlet tube temperature of evaporator

T2: outlet tube temperature of condenser


NOTES:


(1) Measure surface temperature of heat exchanger pipe around center of heat exchanger path U bent. (Thermistor themometer)


(2) Connecting piping condition: 5 m or 4m

3. Construction Views

3.1 Indoor Unit











Model	W	Н	D	Q	R	S
09K	790	265	177	35	605	150
GWH09MA-K3NNA3F GWH09MA-K3NNA3E	/90	265	170	35	605	150

3.2 Outdoor Unit










Unit:mm

4. Refrigerant System Diagram



Refrigerant pipe diameter

Liquid: 1/4" (6 mm) Gas: 3/8" (9.52 mm)

5. Schematic Diagram


5.1 Electrical Data

Symbol	Color symbol	Symbol	Color symbol
WH	WHITE	BN	BROWN
YE	YELLOW	BU	BLUE
RD	RED	вк	BLACK
YEGN	YELLOW GREEN	VT	VIOLET
OG	ORANGE	=	PROTECTIVE EARTH
SAT	OVERLOAD	COMP	COMPRESSOR
GN	GREEN		


5.2 Electrical wiring

Indoor Unit


GWH09MA-K3NNC5A/I GWH09MA-K3NNC8A/I



GWH09MA-K3NNA3F/I




GWH09MA-K3NNA3E/I




Outdoor Unit


GWH09MA-K3NNA3A/O



GWH09MA-K3NNA3F/O



GWH09MA-K3NNA3E/O




These circuit diagrams are subject to change without notice, please refer to the one supplied with the unit.

5.3 Printed Circuit Board


GWH09MA-K3NNC5A GWH09MA-K3NNC8A

• TOP VIEW




NO.	Name	NO.	Name	NO.	Name	NO.	Name
1	PG motor connector	2	Insert of neutral wire	3	Insert of 4-way valve	4	Insert of outdoor fan
5	Solid-state relay	6	Up & down swing connector	7	PG motor feedback connector	8	Relay controlling fan
9	Relay for controlling 4-way valve	10	Connect dispaly1 & 2	11	Indoor tube temperature sensor connector	12	Indoor ambient temperature sensor connector
13	Protective tube	14	Compressor relay and live wire connector	15	Relay controlling cold plasma	16	Piezoresistor
17	Fan capacitor						

BOTTOM VIEW




GWH09MA-K3NNA3E GWH09MA-K3NNA3F

• TOP VIEW



NO.	Name						
1	Compressor connector						
2	Live wire connector of						
	power supply						
3	Indoor fan connector						
4	Neutral wire connector of						
	power supply						
5	4-way valve connector						
6	Outdoor fan connector						
7	Left & right swing connector						
8	Indoor fan state feedback						
	connector						
9	Display connector						
10	Ambient temperature						
	sensor connector						
11	Tube temperature sensor						
	connector						
12	High frequency transformer						

• BOTTOM VIEW



6. Function and Control

6.1 Remote Control Operations

YB1FA



ON/OFF

Press it to start or stop operation

² MODE

Press it to select operation mode(AUTO/COOL/DRY/FAN/HEAT)

- + : Press it to increase temperature setting
- : Press it to decrease temperature setting
- ⁵ FAN

Press it to set fan speed

6

Press it to set swing angle

7 TIMER ON

Press it to set auto-on timer

8 TIMER OFF

Press it to set auto-off timer

9 CLOCK

Press it to set clock

- X-FAN(X-FAN is the alternative expression of BLOW for the purpose of understanding.)
- 11 TEMP
- 12 TURBO
- 13 SLEEP
- 14 LIGHT

Press it to turn on/off the light.

1 ON/OFF:

Press this button to start the unit operation .Press this button again to stop the unit operation.

2 MODE:

Each time you press this button,a mode is selected in a sequence that goes from AUTO,COOL,DRY, FAN,and HEAT *, as the following:



*Note:Only for models with heating function.

After energization, AUTO mode is defaulted. In AUTO mode, the set temperature will not be displayed on the LCD, and the unit will automatically select the suitable operation mode in accordance with the room temp erature to make indoor room comfortable.

3 + :

Press this button to increase set temperature. Holding it down above 2 seconds rapidly increases set temperature. In AUTO mode, set temperature is not adjustable.

4 -:

Press this button to decrease set temperature. Holding it down above 2 seconds rapidly decreases set temperature. In AUTO

mode, set temperature is not adjustable.

5 FAN:

This button is used for setting fan speed in the sequence that goes from AUTO, —, — , def, then back to Auto.

6

Press this button to set up &down swing angle, which circularly changes as below:

7 TIMER ON

Press this button to initiate the auto-ON timer. To cancel the auto-timer program, simply press this button again. After press of this button,

- disappears and "ON "blinks .00:00 is displayed for ON time setting. Within 5 seconds, press + or button to adjust the time value. Every press of either button changes the time setting by 1 minute. Holding down either button rapidly changes the time setting by 1 minute and then 10 minutes. Within 5 seconds after setting, press TIMER ON button to confirm.
- 8 TIMER OFF:

Press this button to initiate the auto-off timer. To cancel the auto-timer program, simply press the button again. TIMER OFF setting is the same as TIMER ON.

9 CLOCK:

Press CLOCK button, blinking. Within 5 seconds, pressing + or - button adjusts the present time. Holding down either button above 2 seconds increases or decreases the time by 1 minute every 0.5 second and then by 10 minutes every 0.5 second. During blinking after setting , press CLOCK button again to confirm the setting, and then will be constantly displayed.

10 X-FAN:

Pressing X-FAN button in COOL or DRY mode, the icon % is displayed and the indoor fan will continue operation for 10 min utes in order to dry the indoor unit even though you have turned off the unit. After energization, X-FAN OFF is defaulted. X-FAN is not available in AUTO, FAN or HEAT mode.

11 TEMP:

Press this button to select displaying set temperature or ambient temperature. When the temperature display is changed from other state to " ______", the ambient temperature is changed. When other signal is received, the set temperature will be displayed. If the user does not set temperature display state, it will display set temperature.

12 TURBO:

Press this button to activate / deactivate the Turbo function which enables the unit to reach the preset temperature in shortest time. In COOL mode, the unit will blow strong cooling air at super high fan speed. In HEAT mode, the unit will blow strong heating air at super high fan speed. (This function is not applicable for some models)

13 SLEEP:

Press this button to go into the SLEEP operation mode. Press it again to cancel. This function is available in COOL, HEAT (Only for models with heating function) or DRY mode to maintain the most comfortable temperature for you.

14 LIGHT:

Press LIGHT button to turn on the display's light and press this button again to turn off the display 's light. If the light is tunrned on , is displayed. If the light is tunrned off disappears.

3 and 4 About lock

Press "+ " and "-" buttons simultaneously to lock or unlock the keypad. If the remote controller is locked, is displayed. In his case, pressing any button, blinks three times.

2 and 4 About switch between fahrenheit and cenrigrade


At unit OFF, press "MODE" and "-" buttons simultaneously to switch between ${}^{\mathbb{C}}$ and ${}^{\mathbb{F}}$.

Replacement of Batteries

- 1.Remove the battery cover plate from the rear of the remote controller.(As shown in the figure)
- 2. Take out the old batteries.
- 3.Insert two new AAA1.5V dry batteries, and pay attention to the polarity.
- 4. Close the battery cover plate.


★ Notes:

- When replacing the batteries, do not use old or different types of batteries. Otherwise, it may cause malfunction.
- If the remote controller will not be used for a long time, please remove batteries to prevent batteries from leaking.
- The operation should be performed in its receiving range.
- It should be kept 1m away from the TV set or stereo sound sets.
- If the remote controller does not operate normally, please take the batteries out and replace them after 30 seconds. If still not operating properly, replace the batteries.



replacing batteries

YB1F4



1 ON/OFF

Press this button to start or stop operation.

2 MODE

Press it to select operation mode(AUTO/COOL/DRY/FAN/HEAT).

- : Press it to decrease temperature setting.
- + : Press it to increase temperature setting.
- FAN Press it to set fan speed.
- HEALTH|SAVE

Press it to select health mode on or off.

- Press it to set left & right swing angle.
- Y-FAN(X-FAN is the alternative expression of BLOW for the purpose of understanding.)
- 10 TEMP
- TIMER
 Press it set auto-on timer/auto-off timer.
- 12 TURBO
- 13 SLEEP
- 14 LIGHT

Press it to turn on/off the light.

Remote controller description

1 ON/OFF:

Press this button to start the unit operation .Press this button again to stop the unit operation.

2 MODE

Each time you press this button,a mode is selected in a sequence that goes from AUTO, COOL,DRY, FAN, and HEAT*, as the following



*Note:Only for models with heating function.

After energization, AUTO mode is defaulted. In AUTO mode, the set temperature will not be displayed on the LCD, and the unit will automatically select the suitable operation mode in accordance with the room temperature to make indoor room comfortable.

3 —:

Press this button to decrease set temperature. Holding it down above 2 seconds rapidly.decreases set temperature. In AUTO mode, set temperature is not adjustable.

4 + :

Press this button to increase set temperature. Holding it down above 2 seconds rapidlyincreases set temperature. In AUTO mode, set temperature is not adjustable.

5 FAN:

This button is used for setting fan speed in the sequence that goes from AUTO, ____, _____, to ______ then back to Auto.



6

- Press 🔰 button to start or stop up & down swing function. The remote controller defaults to simple swing condition.
- Rress + button and button at the same time at unit OFF to switch betweensimple swing and static swing, blinking 2 seconds.
- In static swing condition, press button, the swing angle of up & down louver changes as below:

• If the unit is turned off during swing operation, the louver will stop at present position.

7 HEALTH SAVE:

- HEALTH function: there is no this function for this unit. If press this key, the main unit will click, but it also runs under original status.
- Save energy function: After pressing SAVE button in cooling mode, the unit will turn to SAVE MODE. Meanwhile,remote controller and indoor unit will all display " § §". After pressing SAVE button in heating mode, the unit will turn to 8°C heating mode. Meanwhile, remote controller will display " § § " and indoor unit will display the setting temperature 8°C.

8 氚:

- Press 💻 button to start or stop left & right swing function. The remote controller defaults to simple swing condition.
- Press + button and ____ button at the same time at unit OFF to switch betweensimple swing and static swing,

blinking 2 seconds.

In static swing condition, press 📠 button, the swing angle of left & right louver changes as below:

• If the unit is turned off during swing operation, the louver will stop at present position.

9 X-FAN:

Pressing X-FAN button in COOL or DRY mode, the icon "X-FAN" is displayed and the indoor fan will continue operation for 10 minutes in order to dry the indoor unit even though youhave turned off the unit.

After energization, X-FAN OFF is defaulted. X-FAN is not available in AUTO, FAN or HEAT mode.

10 TEMP:

Pressing TEMP button, (a) (set temperature), (a) (indoor ambient temperature) and (a) (outdoor ambient temperatur) is displayed circularly .The unit defaults not to display the icon. During operation of TEMP button, the set temperature is always displayed.

Note: Outdoor ambient temperature is only displayed for some models.

Press TIMER button at unit ON to set TIMER OFF, HOUR OFF blinking. Press TIMER button at unit OFF to set TIMER ON, HOUR ON blinking. In this case, pressing + or - button changes time setting. Holding down either button rapidly changes time setting (time setting range 0.5-24hours). Press TIMER button again to confirm setting, HOUR ON/OFF stopping blink. If there is not any operation of button within 5 seconds during HOUR ON/OFF blinking, TIMER setting will be canceled.

12 TURBO:

Press this button to activate / deactivate the Turbo function which enables the unit to reach the preset temperature in shortest time. In COOL mode, the unit will blow strong cooling air at super high fan speed. In HEAT mode, the unit will blow strong heating air at super high fan speed. (This function is not applicable for some models).

13 SLEEP:

Press this button to go into the SLEEP operation mode. Press it again to cancel. This function is available in COOL, HEAT (Only for models with heating function) or DRY mode to maintain the most comfortable temperature for you.

14 LIGHT:

Press LIGHT button to turn on the display's light and press this button again to turn off the display's light. If the light is is displayed. If the light is tunrned off idisappears.

4 and 3 About lock:

Press"+ " and "-" buttons simultaneously to lock or unlock the keypad. If the remote controller is locked, is displayed. In this case, pressing any button, blinks three times.

3 and 2 About switch between fahrenheit and cenrigrade


At unit OFF, press "MODE" and "-" buttons simultaneously to switch between $\,^\circ\! \mathbb{C}$ and $\,^\circ\! \mathbb{F}$.

Replacement of Batteries

- 1.Remove the battery cover plate from the rear of the remote controller. (As shown in the figure).
- 2. Take out the old batteries.
- 3. Insert two new AAA1.5V dry batteries, and pay attention to the polarity.
- 4. Replace the battery cover plate.

Notes:

- When replacing the batteries, do not use old or different batteries, otherwise, it may cause malfunction.
- If the wireless remote controller will not be used for a long time, please remove batteries to prevent damage from leaking batteries.
- The operation should be performed in its receiving range.
- It should be kept 1m away from the TV set or stereo sound sets.
- If the wireless remote controller does not operate normally, please take the batteries out and replace them after 30 seconds. If still not operating properly, replace the batteries.



replacing batteries

6.2 Description of Each Control Operation

1Temperature Parameters

- ◆Indoor preset temperature (Tpreset)
- ◆Indoor ambient temperature (Tamb.)

2 Basic Functions (The temperature in this manual is expressed by Centigrade. If Fahrenheit is used, the switchover between them is Tf=TcX1.8+32.)

Once the unit is energized, the compressor shall never be restarted except 3mins interval at least. For the first energization, if the unit is at off status before power failure, the compressor can be restarted without 3-min delay. But if the unit is at on status before power failure, the compressor shall be restarted with 3mins delay. Once the compressor is started up, the compressor won't stop running within 6mins with the change of room temperature.

(1) Cooling mode


1) Cooling conditions and process

When Tamb. ≥Tprese+1℃, the unit starts cooling operation. In this case, the compressor and the outdoor fan operate and the indoor fan operates at set speed.

When Tamb. ≤Tpreset-1°C, the compressor and the outdoor fan stop while the indoor fan operated at set speed.

When Tpreset-1 °C < Tamb. < Tpreset+1 °C, the unit will maintain its previous operation status.


In this mode, the four-way valve is de-energizing. The temperature setting range is $16\sim30^\circ$ C and the indoor unit displays operation icon, cooling icon and set temperature.



2 Protection Functions

Antifreezing protection

If the system is under antifreezing protection, the compressor and the outdoor fan stops operation, and the indoor fan operates at setting speed. If antifreezing protection is eliminated and the compressor has been stopped for 3 minutes, the unit will resume its previous operation status.



(2) Dry Mode


1)Dry Conditions and Process

When Tamb. >Tpreset+2 $^{\circ}$ C, the unit starts drying and cooling operation. In this case, the compressor and outdoor fan operates and the indoor fan operates at low speed.

When Tpreset-2 $^{\circ}$ C $^{\circ}$ Tamb. $^{\circ}$ Tpreset+2 $^{\circ}$ C, the unit will start drying operation. In this case, the indoor fan operates at low speed, and the compressor and the outdoor fan operate 6 minutes and stop 4 minutes in cycle.

When Tamb.<Tpreset-2℃, the compressor and the outdoor fan stops operation while the indoor fan operates at low speed.

In this mode, the four-way valve is de-energizing. The temperature setting range is $16\sim30^\circ$ C and the indoor unit displays operation icon, cooling icon and set temperature.



2 Protection

♦ Antifreezing protection

During drying and cooling operation, if the system is under antifreezing protection, the compressor and outdoor fan stop operation while indoor fan operates at low speed. If antifreezing protection is eliminated and the compressor has been stopped for 3 minutes, the complete unit will resumes its previous operation status.

During the cycle stage of operating 6 minutes and stopping 4 minutes, if antifreezing protection is detected, the compressor and the outdoor fan will stop operation and the indoor fan will operate at low speed. When the antifreezing protection is eliminated and the compressor has been stopped for 4 minutes, the complete unit will resume its previous operation state.

3 Other protection

Other protections are the same as those in cooling mode.

(3) Heating mode (not available for cooling only type)


1) Heating conditions and process

When Tamb. \leq Tpreset+2°C, the unit starts heating operation. In this case, the 4-way valve, compressor and outdoor fan operate simultaneously. The indoor fan operates after 2 minutes at most.

When Tamb≥Tpreset+4°C, the compressor and outdoor fan stop operation. The 4-way valve remains energizing and the indoor fan will stop operation after operate at setting fan speed for 60s.

When $T_{preset} + 2^{\circ}C < T_{amb.} < T_{preset} + 4^{\circ}C$, the unit will maintain its previous operation status.

In this mode, the 4-way valve is energizing. The temperature setting range is $16\sim30^{\circ}$ C and the indoor unit displays operation icon, heating icon and set temperature.



2 Defrosting Conditions and Process

With intelligent defrosting function, the unit can automatically defrost according to the actual condition. The indoor unit displays "H1".

③Protection Functions

◆Overheating Prevention Protection

If the evaporator tube temperature overheats, the outdoor fan stops operation. When the tube temperature resumes normally, the outdoor fan resumes operation.

♦ Noise Silencing Protection

If the unit is turned off by pressing ON/OFF button or during mode switchover, the 4-way valve stops after 2 minutes.

(4) Fan mode

In fan mode, indoor fan operates at setting speed while the compressor, outdoor fan, 4-way valve and electric heating tube stop operation.

In this mode, temperature setting range is $16\sim30^{\circ}$ C. The indoor unit displays operation icon and setting temperature.

(5) Auto Mode

In AUTO mode, the unit will automatically select its operation mode (cooling, heating or fan) with the change of ambient temperature. The indoor unit displays the operation icon, operation mode icon and setting temperature. There is 30-second delay protection for mode switchover. Protection functions are the same as those in any other modes.

3 Other Control

(1)Timer function

General timer and clock timer functions are compatible by equipping different functions of remote controller.

(1) General Timer

Timer ON can be set at unit OFF. If ON time setting is reached, the unit will start to operate according to previous setting status. Time setting range is 0.5-24hr in 30-minute increments.

Timer OFF can be set at unit ON. If OFF time setting is reached, the unit will stop operation. Time setting range is 0.5-24hr in 30-minute increments.

2 Clock Timer

Timer ON

If timer ON is set during operation of the unit, the unit will continue to operate. If timer ON is set at unit OFF, upon ON time reaches the unit will start to operate according to previous setting status.

Timer OFF

If timer OFF is set at unit OFF, the system will keep standby status. If timer OFF is set at unit ON, upon OFF time reaches the unit will stop operation.

Timer Change

Although timer has been set, the unit still can be turned on/off by pressing ON/OFF button of remote controller. You can also set the timer once again, and then the unit will operate according to the last setting.

If timer ON and timer OFF are set at the same time during operation of the unit, the unit will keep operating at current status till OFF time reaches.

If timer ON and timer OFF are set at the same time at unit OFF, the unit will keep stop till ON time reaches.

In the future's every day, the system will operate according to presetting mode till OFF time reaches and stop operation till ON time reaches. If ON time and OFF time are the same, timer OFF has the priority.

(2) Auto Button

If this button is pressed, the unit will operate in AUTO mode and indoor fan will operate at auto speed; meanwhile, the swing motor operates. Press this button again to turn off the unit.

(3) Buzzer

Upon energization or availably operating the unit or remote controller, the buzzer will give out a beep.

(4) Sleep Function

In this mode, the unit will select the suitable sleep curve to operate according to the setting temperature.

(5)Turbo Function

This function can be set in cooling or heating mode to quickly cool or heat the room.

(6) X-Fan Function

This function can be set in COOL or DRY mode.

(7) Automatic Control of Fan Speed

In this mode, the indoor fan will automatically select high, medium or low speed with the change of ambient temperature.


(8)Up & Down Swing

After energization, up & down swing motor will firstly let the horizontal louver anticlockwise rotate to position 0 to close air outlet.

If swing function has not been set after startup of the unit, up & down horizontal louver will clockwise turn to position D in HEAT mode, or clockwise turn to level position L in other modes.

If setting swing function while starting up the unit, the horizontal louver will swing between L and D. There are 7 kinds of swing status of horizontal louver: Positions L, A, B, C and D, swing between L and D and stop at any position between L and D (angles between L and D are equiangular). Upon turning off the unit, the horizontal louver will close at position 0. Swing function is available only when swing function set and indoor fan is operating.

Note: If the position is set between L and B, A and C or B and D by remote controller, the horizontal louver will swing between L and D.



Upon energization, the unit will display all icons. Under standby state, operation indicator is displayed in red. If the unit is started by remote controller, the operation icon will give off light; meanwhile, the current setting running mode icon and fan mode icon will be displayed(mode LED: cooling, heating and dry mode). If the light button is turned off, all marks display will be disappeared.

2 Display of Dual-8 Nixie Tube

For the first time of startup , the indoor unit defaults to display present set temperature $(16\sim30^{\circ}\text{C})$. Then if set temperature display is set by remote controller, it will display set temperature and if room temperature display is set, it will display room temperature. After that, if you operate the remote controller for other settings, the temperature display method will keep original. If you operate the remote controller during room temperature display, the set temperature will be displayed for 5 seconds firstly and then room temperature display returns. "F1" will be displayed upon malfunction of room temperature sensor, "F2" upon malfunction of indoor unit tube temperature sensor and "C5" upon malfunction of jumper cap. For some models, if set temperature display is set by the remote controller, present set temperature will be displayed. After that, when you set room temperature display from set temperature display or outdoor temperature by the remote controller, the room temperature will be displayed for 5 seconds firstly and then set temperature display returns.

(10) Locked protection to PG motor

When starting the fan, if motor's rotational speed is slow for a period of time, the unit will display locked and stop running to avoid auto protection for motor. If the unit is at on status currently, error code H6 will be displayed on the nixie tube. If the unit is off currently, this locked malfunction information won't be displayed.

(11)Memory Function

Memory content includes mode, up & down swing, light, set temperature and set fan speed, general timer (clock timer can't be memorized), Fahrenheit/Centigrade..

Upon power failure, the unit after power recovery will automatically start operation according to memorized content. The unit, without timer setting before power failure, will operate according to the last setting after power recovery. The unit, with general timer setting which has not been fulfilled before power failure, will memorize the time setting and re-calculate the time after power recovery. If there is timer function in the last remote controller command but setting time has reached, the system will act as timer on/off setting before power failure. After power failure, the system memorizes the operation states before power failure without timer action. Clock timer can not be memorized.

7. Installation Manual

7.1 Notices for Installation



Important Notices

- 1. The unit must only be installed by Authorised Service Center according to municipal or government regulations and in compliance with this manual.
- 2.Before installating, please contact with local authorized maintenance center. If unit is not installed by the Authorised Service Center, the malfunction may not be solved due to discommodious contacts.
- 3. When removing the unit to the other place, please firstly contact with the Authorized Service Center in the local area.

Basic Requirements For Installation Position

Proper installation location is vital for correct and efficient operation. Avoid the following locations where:

- strong heat sources, vapours, flammable gas or volatile liquids are emitted.
- high-frequency electro-magnetic waves are generated by radio equipment, welders and medical equipment
- salt-laden air is a problem (such as close to coastal areas).
- the air is contaminated with industrial vapours and oils.
- the air contains sulphures gas such as in hot spring zones.
- Other environments where corrosion or air quality is a problem.

Installation Location Selection of Indoor Unit

- 1. The air inlet and outlet vent should be away from the obstruction. Ensure the air can be blown through the whole room.
- 2. Select a location where the condensing water can be easily drained out, and where it is easily connected for outdoor unit.
- 3. Select a place where the children can not reach.
- 4.Select the place where the wall is strong enough to withstand the full weight and vibration of the unit, and will not increase the noise.
- 5.Be sure to leave enough space to allow access for routine maintenance. The height of the installed location should be 250cm or more above the floor.
- 6.Select a place about 1m or more away from TVset or any other electric appliances.
- 7. Select a place where the filter can be easily taken out.
- 8.Make sure that the indoor unit is installed in accord with installation dimension insturctions.
- 9.Do not use the unit in the laundry or the bathroom or around the swimming pool etc.

Installation Loctaion Selection of Outdoor Unit

- 1.Select a location from which noise and outflow air emitted by unit will not inconvenience neighbors, animals and plants.
- 2. Select a location where there is sufficient ventilation.
- 3. Select a location where there is no obstructions which will cover the inlet and outlet vents
- 4.The location should be able to withstand the full weight and vibration of the outdoor unit and permit safe installation.
- 5. Select a dry place, but do not expose under the direct sunlight or strong wind.
- 6.Make sure that the outdoor unit is installed in accord with the installation instructions, and is convenient for maintenance and repair.
- 7.The height difference between indoor and outdoor units is within 5 m, and the length of the connecting tubing does not exceed 10 m.
- 8. Select a place where it is out of reach for the children.
- 9. Select a place which will not block pedestrian passage and influence the city appearance.

Safety Requirements For Electric Appliances

- 1. A dedicated power supply circuit should be used in accordance with local electrical safety regulations.
- 2. Don't drag the power cord emphatically.
- 3. The unit should be reliably earthed and connected to the special earth device by the professionals.

The air switch must have the functions of magnetic tripping and heat tripping to prevent short circuit and overloading.

- 4. The min. distance between the unit and combustive surface is 1.5m.
- 5. The appliance shall be installed in accordance with national wiring regulations.
- 6.An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.


NOTE:

- Make sure the live wire ,neutral wire and earth wire in the family power socket are properly connected. There should be reliable circuit in the diagram.
- Inadequate or incorrect electrical connections may cause electrocution or fire.

Earthing requirements

- 1.Air conditioner is type I electric appliance. Please ensure the the unit is reliably earthed.
- 2. The yellow-green two-color wire in air conditioner is the earthing wire which can not be used for other proposes. Improper earthing may cause electrocution.
- 3. The earth resistance should accord to the National Criterion.
- 4. The user's power must have reliable earthing terminal. Please don't connect the earthing wire with the following:
- ①Tap water pipe ② Gas pipe ③ Contamination pipe
- ①Other places that professional personnel consider is unreliable
- 5. The model and rating values for fuses accord with the silk print on fuse cover or related PCB board.

7.2 Installation Drawing




The above diagram is only for reference.

7.3 Installing Indoor Unit


Installing Mounting Plate

- 1.Make the mounting plate completely level . As the water tray's oulet of the indoor unit is two-way type, the indoor unit during installation should slightly slant to watert tray's outlet for smooth drainage of condensing water.
- 2.Fix the mounting plate on the wall with screws.(Where is pre-covered with plastic granula)
- 3.Be sure that the mounting plate has been fixed firmly enough to withstand the weight of an adult of 60kg; further more, the weight should be evenly shared by each screw.



Boring Piping Hole


- 1.Make the piping hole ($\!\Phi$ 55) in the wall at a slight downward slant to the outdoor side.
- 2.Insert the piping-hole sleeve into the hole to prevent the connection piping and wiring from being damaged when passing through the hole.



● Installing Drain Hose


- 1.Connect the drain hose to the outlet pipe of the indoor unit. Bind the joint with rubber belt.
- 2.Put the drain hose into insulating tube.
- 3.Wrap the insulating tube with wide rubber belt from the joint of outlet pipe and insulating pipe so as to prevent shift of insulating tube. The drain hose should be placed at a downward slant for easy discharge of condensate.

Note: the insulating tube should be connected reliably with the sleve outside the outlet pipe. The drain hose should be downward slant, without distortion, bulge or fluctuation. Do not put the water outlet in the water.



Connecting Indoor and Outdoor Electric Wires

- 1. Open the front panel.
- 2. Remove the wiring cover as shown in Fig 6.
- 3.Make the power connection cord and signal control wire (only for heat pump unit) through the hole in the back of indoor unit.
- 4. Reinstall the clamp and wiring cover.
- 5.Recover the front panel.




NOTE:

All interconnecting wiring between indoor and outdoor unit must be performed by a licenced electrical contractor

- The electric wiring must be correctly connected. Improper connection may cause spare parts malfunction.
- Tighten the terminal screws adequately to prevent loosening.
- After tightening the screws, slightly pull the wire and confirm whether it is firm or not.
- Ensure the electrical connections are properly earthed to prevent electrical shocks.
- Ensure all wiring connections are secure and the cover plates are reinstalled properly. Poor installations that allow dust or moisture incursion may cause fire or electrocution.

Installing Indoor Unit


- The piping can be output from right, right rear, left or left rear.
- 1. When routing the piping and wiring from the left or right side of indoor unit, cut off the tailings from the chassis as necessary(As shown in Fig.7) (1) Cut off the tailings 1 when routing the wiring only; (2) Cut off the tailings 1 and tailings 2 when routing both the wiring and piping.
- 2. Take out the piping from body case, wrap the piping, power cords, drain hose with the tape and make them through the piping hole. (As shown in Fig. 8)
- 3.Hang the mounting slots of the indoor unit on the upper hooks of the mounting plate and check if it is firm enough.(As shown in Fig.9)
- 4. The height of the installed location should be 2m or more from the floor.



Installing Connection Pipe

- 1. Align the center of the piping flare with the relevant valve.
- 2. Screw in the flare nut by hand and then tighten the nut with spanner and torque wrench referring to the following:

Hex nut diameter	Tightening torque(N⋅m)		
Ф6	15~20		
Ф 9.52	31~35		
Ф 12	50~55		
Ф 16	60~65		
Ф 19	70~75		




NOTE: Firstly connect the connection pipe to indoor unit, then to outdoor unit; pay attention to the piping bending, do not damage the connection pipe; ensure the joint nut is adequately tightened, otherwise it may cause leakage.

7.4 Install Outdoor Unit

Electric Wiring

- 1. Remove the handle on the outdoor unit's right side plate.
- 2.Take off wire clamp. Connect and fix power connection cord and signal control wire (only for heat pump type)to the terminal board.Wiring should fit that of indoor unit.
- 3.Fix the power connection cord and signal control wire (only for heat pump type) with wire clamps and then connect the corresponding connector.

4.Confirm if the wire has been fixed properly.5.Reinstall the handle.



NOTE:

- Incorrect wiring may cause spare parts malfunction.
- After the wire has been fixed, ensure there is free space between the connection and fixing places on the lead wire.

Air Purging and Leakage Test

- 1. Connect charging hose of manifold valve to charge end of low pressure valve (both high/low pressure valves must be tightly shut).
- 2. Connect joint of charging hose to vacuum pump.
- 3. Fully open the handle of Lo manifold valve.
- 4. Open the vacuum pump to evacuate. At the beginning, slightly loosen joint nut of low pressure valve to check if there is air coming inside. (If noise of vacuum pump has been changed, the reading of multimeter is 0) Then tighten the nut.
- Keep evacuating for more than 15mins and make sure the reading of multi-meter is-1.0 X10⁵ pa (-76cmHg).
- 6. Fully open high/low pressure valves.
- 7. Remove charging hose from charging end of low pressure valve.
- 8. Tighten bonnet of low pressure valve. (As shown in Fig.10)





Fig.10

Outdoor Condensation Drainage (only for Heat pump type)

During heating operation, the condensing water and defrosting water should be drained out reliably through the drain hose. Install the outdoor drain connector in a Φ 25 hole on the the base plate and attach the drain hose to the connector, so that the waste water formed in the outdoor unit can be drained out satisfactorily.



7.5 Install Quick Connector

Operating Process	Photos
1. Screw out bolt pointed byarrow.	Bolt
2. Press big handle downwardand take it off.	
3. Undo the tighten plate onquick connector (male).	Orientating pin Tighten plate
4. Pull the tighten noose inwardby the arrow direction.	Tighten noose

Operating Process	Photos
 Insert quick connector(male) into root of the female one, and reposit tightening noose at the same time. Note: Make orientating pin downward. 	
6. Rotate tighten plate andpress it to bottom. Note: It is hard to press tighten plate to bottom if tighten noose doesn't reposited thoroughly.	en plate
7.Connect the wiring terminal fix the earthing wiring with screw to the metal electric box. Install wire clamp to tighten connection wire.	Wire clamp Connection terminal
8. Install big handle.	

7.6 Check after Installation and Operation Test

Check after Installation

Items to be checked	Possible malfunction
Has it been fixed firmly?	The unit may drop, shake or emit noise.
Have you done the refrigerant leakage test?	It may cause insufficient cooling(heating)capacity
Is heat insulation sufficient?	It may cause condensation and dripping.
Is water drainage satisfactory?	It may cause condensation and dripping.
Is the voltage in accordance with the rated voltage marked on the nameplate?	It may cause electric malfunctionor damage the product.
Is the electric wiring and piping connection installed correctly and securely?	It may cause electric malfunction or damage the part.
Has the unit been connected to a secure earth connection?	It may cause electrical leakage.
Is the power cord specified?	It may cause electric malfunctionor damage the part.
Are the inlet and outlet openings blocked?	It may cause insufficient cooling(heating) capacity.
Is the length of connection pipes and refrigerant capacity been recorded?	The refrigerant capacity is not accurate.

Operation Test


- 1.Before Operation Test
- (1)Do not switch on power before installation is finished completely.
- (2)Electric wiring must be connected correctly and securely.
- (3)Cut-off valves of the connection pipes should be opened.
- (4)All the impurities such as scraps and thrums must be cleared from the unit.
- 2. Operation Test Method
- (1)Switch on power and press "ON/OFF" button on the wireless remote controllerto start the operation.
- (2)Press MODE button to select the COOL, HEAT (Cooling only unit is not available), FAN to check whether the operation is normal or not.


7.7 Installation and Maintenance of Healthy Filter(Optional)


Installation of Healthy Filter


1.Lift up the front panel from the two ends of it, as the arrow direction shown. Then pull the air filter out.(as shown Fig.a)

2.Attach the healthy filter onto the air filter, (as shown Fig.b)









Cleaning and Maintenance

Remove the healthy filter before cleaning and reinstall it after clean according to the installation instruction, but can't with brush or hard things. After washing, be sure to shake off remaining water and dry in the shade.

Service Life

The healthy filter commonly has its usage lifetime for one year under normal condition. As for silver ion filter, it is invalid when its surface becomes black (green).


This supplementary instruction is provided for reference to the unit with healthy filter. If the graphics provided herein is different from the physical goods, the latter one shall prevail.

The quantity of healthy filters shall be based on the actual delivery.

8. Exploded Views and Parts List


8.1 Indoor Unit

GWH09MA-K3NNC5A/I GWH09MA-K3NNC8A/I




NO.	Description	Part Code			
	Description	GWH09MA-K3NNC8A/I	GWH09MA-K3NNC5A/I	Qty	
	Product Code	CA192N0010	CA179N0040	1	
1	Front Panel Assy	2001235204	20012611	1	
2	Filter Sub-Assy	11122081	11122081	2	
3	Screw Cover	242520172	24252016	3	
4	Electric Box Cover2	2010249602	20122075	1	
5	Front Case	2001212004P	20012179	1	
6	Axile Bush	10542008	10542008	1	
7	Guide Louver	1051211102P	10512111	1	
8	Air Louver 1	1051211301	10512113	1	
9	Air Louver 2	1051211401	10512114	1	
10	Helicoid tongue	2611216201	26112162	1	
11	Axile Bush	10542704	10542704	1	
12	Rear Case assy	2220210108	2220210101	1	
13	Cross Flow Fan	10352018	10352018	1	
14	Fan Bearing	76512210	76512210	1	
15	O-Gasket sub-assy of Bearing	76512051	76512051	1	
16	O-Gasket of Cross Fan Bearing	76512203	76512203	1	
17	Ring of Bearing	26152022	26152022	1	
18	Remote Controller	30510041	30510041	1	
19	Drainage hose	0523001406	0523001406	1	
20	Wall Mounting Frame	01252015	01252015	1	
21	Evaporator Assy	0100255202	0100255202	1	
22	Evaporator Support	24212090	24212090	1	
23	Connecting Cable	40020540	40020540	1	
24	Connecting Cable	necting Cable 40020536 40020536		1	
25	Power Cord	ver Cord 400220113 400220113		1	
26	Tube Sensor	390000591 390000591		1	
27	Ambient Temperature Sensor	390000453	390000453	1	
28	Main Board	30035564	30035564	1	
29	Terminal Board	42010262	42010262	1	
30	Electric Box	20112082	20112082	1	
31	Transformer	43110236	43110236	1	
32	Electric Box Assy	20202532	2020203712	1	
33	Display Board	30565083	3056504301	1	
34	Crank	10582070	10582070	1	
35	Step Motor	1521210801	1521210801	1	
36	Rubber Plug (Water Tray)	76712012	76712012	1	
37	Motor Press Plate	26112160	26112160	1	
38	Fan Motor	15012115	15012115	1	
39	Pipe Clamp	26112164	26112164	1	
40	Jumper	4202300128	4202300128	1	
41	Capacitor CBB61	33010002	33010002	1	
42	Shield cover of Electric Box sub-assy	0159207301	0159207301	1	
43	Shield cover of Electric Box	0141203601	0141203601	1	
44	Electric Box Cover1	20122103	20122103	1	

GWH09MA-K3NNA3E/I




	D	Part Code	
NO.	Description	GWH09MA-K3NNA3E/I	Qty
	Product Code	CA171N0800	
1	Front Panel Assy	20012241	1
2	Front panel B1	20012121S	1
3	Filter Sub-Assy	11122081	2
4	Screw Cover	24252016	3
5	Electric Box Cover2	20122075	1
6	Front Case	20012120	1
7	Axile Bush	10542008	1
8	Guide Louver	10512111	1
9	Air Louver 1	10512113	1
10	Air Louver 2	10512114	1
11	Helicoid tongue	26112162	1
12	Axile Bush	10542704	1
13	Rear Case assy	2220210101	1
14	Cross Flow Fan	10352018	1
15	O-Gasket sub-assy of Bearing	76512051	1
16	Ring of Bearing	26152022	1
17	Remote Controller	30510091	1
18	Drainage hose	0523001406	1
19	Vall Mounting Frame 01252015		1
20	Evaporator Assy	01002611	1
21	Evaporator Support	24212090	1
22	Power Cord	400220113	1
23	Soft Pipe Assy	05232040	1
24	Pipe Clamp	26112164	1
25	Fan Motor	15012115	1
26	Motor Press Plate	26112160	1
27	Rubber Plug (Water Tray)	76712012	1
28	Step Motor	1521210801	1
29	Crank	10582070	1
30	Display Board	30565007	1
31	Electric Box Assy	20202469	1
32	Electric Box	2011210501	1
33	Terminal Board	42010262	1
34	Electric Box Cover1 20122103		1
35	Shield cover of Electric Box sub-assy 0159207301		1
36	Main Board	30135550	1
37	Tube Sensor	390000591	1
38	Ambient Temperature Sensor	390000453	1
39	Jumper	4202300128	1

GWH09MA-K3NNA3F/I



	Para de fina	Part Code		
NO.	Description	GWH09MA-K3NNA3F/I	Qty	
	Product Code	CA171N0680		
1	Front Panel Assy	20012241		
2	Front panel B1	20012121S	1	
3	Filter Sub-Assy	11122081	2	
4	Screw Cover	24252016	3	
5	Electric Box Cover2	20122075	1	
6	Front Case	20012120	1	
7	Axile Bush	10542008	1	
8	Guide Louver	10512111	1	
9	Air Louver 1	10512113	1	
10	Air Louver 2	10512114	1	
11	Helicoid tongue	26112162	1	
12	Axile Bush	10542704	1	
13	Rear Case assy	2220210101	1	
14	Cross Flow Fan	10352018	1	
15	Fan Bearing	76512210	1	
16	O-Gasket sub-assy of Bearing	76512051	1	
17	O-Gasket of Cross Fan Bearing	76512203	1	
18	Ring of Bearing	26152022	1	
19	Remote Controller	30510091	1	
20	Drainage hose	0523001406	1	
21	Wall Mounting Frame	01252015	1	
22	Evaporator Assy	0100255202	1	
23	Evaporator Support	24212090	1	
24	Connecting Cable	400205235	1	
25	Connecting Cable	40020536	1	
26	Power Cord	400220113	1	
27	Pipe Clamp	26112164	1	
28	Fan Motor	15012115	1	
29	Motor Press Plate	26112160	1	
30	Rubber Plug (Water Tray)	76712012	1	
31	Step Motor	1521210801	1	
32	Crank	10582070	1	
33	Display Board	30565007	1	
34	Electric Box Assy	20202474	1	
35	Electric Box	2011210501	1	
36	Terminal Board	4201026201	1	
37	Electric Box Cover1	20122103	1	
38	Shield cover of Electric Box sub-assy 0159207301		1	
39	Shield cover of Electric Box 0141203601		1	
40	Main Board	30135550	1	
41	Tube Sensor	390000591	1	
42	Ambient Temperature Sensor	390000453	1	
43	Jumper	4202300128	1	


GWH12MB-K3NNC9A/I



	Description	Part Code	
NO.	Description	GWH12MB-K3NNC9A/I	Qty
	Product Code	CA145N0020	
1	Front Panel Sub-Assy	20012743	1
2	Display Board	30565056	1
3	Filter Sub-Assy	1112220403	2
4	Electric Box Cover2	20122075	1
5	Screw Cover	24252016	1
6	Front Case Sub-Assy	20012139	1
7	Axile Bush	10542008	1
8	Guide Louver	10512157	1
9	Air Louver 1	10512156	1
10	Air Louver 2	10512155	1
11	Helicoid tongue	26112163	1
12	Left Axile Bush	10512037	1
13	Rear Case assy	2220210301	1
14	Cross Flow Fan	10352017	1
15	O-Gasket sub-assy of Bearing	76512051	1
16	Ring of Bearing	26152022	1
17	Drainage hose	0523001401	1
18	Wall Mounting Frame	01252021	1
19	Evaporator Assy	0100256401	1
20	Evaporator Support	24212091	1
21	Connecting Cable	40020536	1
22	Connecting Cable	400205401	1
23	Power Cord	400220112	1
24	Pipe Clamp	26112164	1
25	Fan Motor	150120874	1
26	Motor Press Plate	26112161	1
27	Rubber Plug (Water Tray)	76712012	1
28	Step Motor	1521210801	1
29	Crank	10582070	1
30	Electric Box Assy	2020207601	1
31	Transformer	43110236	1
32	Electric Box	20112082	1
33	Terminal Board	42010262	1
34	Shield cover of Electric Box sub-assy	0159207301	1
35	Electric Box Cover1	20122103	1
36	Radiator	49010252	1
37	Capacitor CBB61 33010002		1
38	Jumper	4202300130	1
39	Ambient Temperature Sensor 390000453		1
40	Main Board	30035566	1
41	Tube Sensor	390000591	1
42	Remote Controller	30510041	1


8.2 Outdoor Unit

GWH09MA-K3NNA3A/O GWH12MB-K3NNA4A/O




NO.	Description	Part	Part Code			
	Description	GWH09MA-K3NNA3A/O	GWH12MB-K3NNA4A/O	Qty		
	Product Code	CA155W0070	CA155W0030			
1	Front grill	22413433	22413433	1		
2	Front Panel	015330124	015330124	1		
3	Chassis Sub-assy	01203659P	0120322910	1		
4	Magnet Coil	43000400	43000400	1		
5	Compressor and fittings	00103082	00120223	1		
6	4-way Valve Assy	03123018	03023959	1		
7	Capillary Sub-Assy	0310349702	03003946	1		
8	Right Side Plate Assy	0130200403	0130200404	1		
9	Valve	07100005	07100006	1		
10	Valve	07100003	07100003	1		
11	Big Handle	26233433	26233433	1		
12	Valve Support	01713041	01713041	1		
13	Terminal Board	42010265	42010265	1		
14	Capacitor CBB65	33000018	33000018	1		
15	Capacitor CBB61	33010025	33010025	1		
16	Terminal Board	42011147	42011147	1		
17	capacitor clamp sub	02143401	02143401	1		
18	Electric Box Assy	0140386101	0140314501	1		
19	Rear grill	11123205	11123205	1		
20	Top Cover Plate	1253443	01253443	1		
21	Condenser Assy	0110395702	0110348418	1		
22	Clapboard Sub-Assy	012334172	012334172	1		
23	Motor Support Sub-Assy	01703053	017030511	1		
24	Fan Motor	150130671	15013067	1		
25	Axial Flow Fan	10333004	10333004	1		

GWH09MA-K3NNA3E/O



NO.	Description	Part Code	Qty
	Description	GWH09MA-K3NNA3E/O	
	Product Code	CA171W0800	
1	Front grill	22413431	1
2	Front Panel	015330124	1
3	Chassis Sub-assy	01203945P	1
4	Magnet Coil	43000400	1
5	Compressor and fittings	00103082	1
6	Compressor Gasket	76711004	3
7	Overload Protector	00183009	1
8	4-way Valve	430004022	1
9	4-way Valve Assy	03123398	1
10	Right Side Plate Assy	0130308601	1
11	Valve Support	01703081	1
12	Quick Connector Assy	06393026	1
13	Big Handle	26233433	1
14	Electric Box Assy	02603361	1
15	Capacitor CBB65	33000018	1
16	Capacitor CBB61	33010025	1
17	Terminal Board	42011103	1
18	Capillary Sub-Assy	0310349702	1
19	Filter	07210022	1
20	Condenser Assy	0110395702	1
21	Rear grill	11123205	1
22	Top Cover Plate	01253443	1
23	Clapboard Sub-Assy	012334172	1
24	Motor Support Sub-Assy	01703053	1
25	Fan Motor	150130671	1
26	Axial Flow Fan	10333004	1
27	Drainage Connecter	06123401	1

GWH09MA-K3NNA3F/O



	Description	Part Code		
NO.	Description	GWH09MA-K3NNA3F/O	Qty	
	Product Code	CA171W0680		
1	Front grill	22413433	1	
2	Front Panel	015330124	1	
3	Chassis Sub-assy	01203945P	1	
4	Magnet Coil	43000400	1	
5	Compressor and fittings	00103082	1	
6	4-way Valve Assy	03123018	1	
7	Capillary Sub-Assy	0310349702	1	
8	Right Side Plate Assy	0130200403	1	
9	Valve	07100005	1	
10	Valve	07100003	1	
11	Big Handle	26233433	1	
12	Valve Support	01713041	1	
13	Terminal Board	420101941	1	
14	Capacitor CBB65	33000018	1	
15	Terminal Board	42011147	1	
16	Capacitor CBB61	33010025	1	
17	Terminal Board	42011103	1	
18	Thermostat	45040026	1	
19	Electric Box Assy	02603376	1	
20	Rear grill	11123205	1	
21	Top Cover Plate	01253443	1	
22	Condenser Assy	0110395702	1	
23	electrical heater	76513502	1	
24	Clapboard Sub-Assy	012334172	1	
25	Motor Support Sub-Assy	01703053	1	
26	Electrical heater (Chassis)	76510005	1	
27	Fan Motor	150130671	1	
28	Axial Flow Fan	10333004	1	
29	Drainage Connecter	06123401	1	


9. Troubleshooting

9. 1 Malfunction Codes


		Display Method of Indoor Unit			Unit		
			Indicator lamp		A/C Status		
	Malfunction Name		(During blinking, ON for				
No.		Error Code	0.5S and OFF for 0.5 S)			Possible Causes	
		0000	Operation	COOL	HEAT		
			Lamp	Lamp	Lamp		
1	Indoor ambient temperature sensor is open/short- circuited	F1		OFF 3S and blinks once		The unit will stop operation as it reaches the temperature point. During cooling and drying operation, except indoor fan operates, other loads (such as compressor, outdoor fan, 4-way valve) stop operation; During heating operation, the complete unit stops operation.	The wiring terminal between indoor ambient temperature sensor and controller is loosened or poorly contacted; There's short circuit due to trip-over of the parts on controller; Indoor ambient temperature sensor is damaged (Please check it by referring to the resistance table for temperature sensor) Main board is broken.
2	Indoor evaporator temperature sensor is open/short-circuited			OFF 3S and blinks twice		The unit will stop operation as it reaches the temperature point. During cooling and drying operation, except indoor fan operates, other loads stop operation; During heating operation, the complete unit stops operation.	1. The wiring terminal between indoor evaporator temperature sensor and controller is loosened or poorly contacted; 2. There's short circuit due to the trip-over of the parts on controller; 3.Indoor evaporator temperature sensor is damaged (Please check it by referring to the resistance table for temperature sensor) 4. Main board is broken.
3	PG motor (indoor fan motor) does not operate		OFF 3S and blinks 11 times			Indoor fan, outdoor fan, compressor and electric heat tube stop operation. 2 minutes later, 4-way valve stops; horizontal louver stops at the current position.	 The feedback terminal of PG motor is not connected tightly. The control terminal of PG motor is not connected tightly. Fan blade rotates unsmoothly due to improper installation. Motor is not installed properly and tightly. Motor is damaged. Controller is damaged.
4	Malfunction protection of jumper cap	C5	OFF 3S and blinks 15 times			Operation of remote controller or control panel is available, but the unit won't act.	 There's not jumper cap on the controller. Jumper cap is not inserted properly and tightly. Jumper cap is damaged. Controller is damaged.
5	PG motor (indoor fan) circuit malfunction by zero cross detection		OFF 3S and blinks 17 times			Operation of remote controller or control panel is available, but the unit won't act.	Controller is damaged.

9.2 How to Check simply the main part


(1) PG motor (indoor fan) does not operate (H6)




(2)Open circuit, short circuit of temperature sensor (F1, F2)



(3) Jumper cap malfunction (C5)



(4) PG motor (indoor fan) circuit detection by zero crossing detection (U8)



The above information is only for refrence.

10. Removal Procedure

10.1 Removal Procedure of Indoor Unit

Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure					
1. Re	emove the filter					
а	Open the front panel.	panel				
b	Loosen the clasp of the filter.	clasp				
С	Take out the filter.	filter				
2. Re	move the horizontal louver					
а	Remove the axile bush on the horizontal louver.	axile bush				

Step	Proce	dure
b	Pull the horizontal louver outward to remove it.	horizontal louver
3. R	emove the panel	
а	Push the rotor shaft on both sides of the panel to make it separate from the groove. Remove the panel.	panel panel
4.	Remove the electric box cover	
а	Loosen the 2 screws of the electric box cover.	screw

Step	Pro	cedure
b	Remove the electric box cover.	electric box cover
5. R	emove the front case	
а	Open the screw cap on the front case. Remove the screws fixing the front case.	screw
b	Loosen the clasps of the front case.	clasp
С	Remove the front case.	left middle right front case

Step	Pr	ocedure
6. R	lemove the vertical louver	
а	Loosen the clasp connecting the vertical louver and bottom case subassembly.	clasp
b	Remove the vertical louver.	vertical louver
7. F	Remove the electric box cover	
а	Disconnect the indoor tube temperature sensor.	Heat exchanger thermistor
b	Remove the screws of the electric box.	SCrew
С	Remove the screws at the joint of the ground wire and evaporator.	screw ground wire

Step	Proc	cedure
d	Loosen the clasp at the joint of the electric box cover and the electric box.	
е	Disconnect the plug of the motor.	clasp fan motor signal wire
f	Disconnect the plug of step motor.	plug of step motor
g	Remove the 2 screws of the display.	SCrew
h	Remove the electric box.	electric box

Step		Procedure
8. Re	emove the mainboard	
а	Loosen the screws on the wiring board. Pull out the connecting wire.	screws
b	Take out the mainboard from the electric box.	mainboard
9.	Remove press plate of connecting pipe	
а	Remove the screws of the press plate of connecting pipe.	Pipe Clamp Auxiliary Piping screw
b	Remove press plate of connecting pipe.	Pipe Clamp

Step	Proce	edure
10.	Remove the evaporator	
а	Remove the screws at the joint of the evaporator and bottom case.	screws
b	Adjust the pipe slightly to separate the connecting pipe and the evaporator.	Auxiliary Piping
С	Remove the evaporator.	Heat Exchanger
11.	Remove motor and cross flow fan	
а	Remove the screw of the step motor and remove the step motor.	Step Motor

Step	Pro	cedure
b	Remove the screw of the motor press plate. Remove the press plate.	Motor Press Plate
С	Remove the cross flow blade and motor.	cross flow blade motor
d	Remove the rubber cushion of the bearing.	O - Gasket sub-assy of Bearing Ring of Bearing
е	Remove the screws at the joint of the cross flow blade and the motor. Take down the motor.	cross flow blade motor

10.2 Removal Procedure of Outdoor Unit

Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Proced	dure
1. Be	fore disassembly	
	Before disassembly	
2. Rer	move big hanging ring	
	Loosen the screw fixing the hanging ring. Remove the hanging ring.	big hanging ring
3. F	Remove top cover	*>0
	Loosen the screw fixing connecting the top cover, panel and right-side panel.	Top panel

Step **Procedure** 4. Remove front grille Loosen the screw fixing the front grille and panel. Remove the front grille. front grille 5. Remove the front panel Loosen the screw fixing the front panel, chassis and motor support. Remove the front panel. front panel 6. Remove the right-side panel right-side panel Remove the screw fixing the right-side panel, chassis, valve support and electric box. Remove the right-side panel. 7. Remove the axial flow blade axial flow blade Loosen the screw fixing the blade. Remove the axial flow blade.

Step **Procedure** 8. Remove motor and motor support Loosen the tapping screws fixing the motor support motor. Disconnect the leading wire of motor. Remove the motor. Loosen the tapping screws fixing the motor support. Raise the support to remove it. motor 9. Remove electric box subassembly electric box Loosen the screws fixing the electric box subassembly. Loosen the binding line and disconnect the wiring terminal. Raise the electric box to remove it. 10. Remove isolation sheet Loosen the 3 screws fixing the isolation isolation sheet sheet. 11. Remove sound-proof sponge Remove the sound-proof sponge wrapping the compressor. sound-proof sponge —

Step	Proc	edure
12. F	Remove magnetic coil Remove the screw of the magnetic coil. Remove the magnetic coil.	magnetic coil
13.F	Remove the gas valve and liquid valve	magnette son
	Solder off the capillary, the valve and condensate outlet pipe. Do not block the capillary when replacing it. Loosen the 2 screws fixing the gas valve. Solder off the gas valve and return air duct. (note: when soldering off the gas valve, wrap it with wet cloth to avoid damage by high temperature.) Loosen the 2 screws fixing the liquid valve. Solder off the liquid valve.	liquid valve gas valve
14. R	emove compressor	4-way valve
а	Discharge the refrigerant. Solder off the pipe connecting the compressor (including 4-way valve, compressor, condenser, capillary.) Do not block the capillary during soldering.	Capillary
b	Loosen the ground bolts fixing the compressor. Then remove the compressor.	compressor

10.3 Removal Procedure of Outdoor Unit (Quick Coupler)

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Proced	dure
1. Bef	ore disassembly	
	Before disassembly	
2. Ren	nove big hanging ring	
	Loosen the screw fixing the hanging ring. Remove the hanging ring.	big hanging ring
3. R	emove top cover	~
	Loosen the screw fixing the top cover, panel and right-side panel. Remove the top cover.	Top panel

Step	Proc	edure
4. Re	emove front grille	
	Loosen the screw fixing the front grille and panel. Remove the front grille.	front grille
5. Re	move the front panel	
	Loosen the screw fixing the front panel, chassis and motor support. Remove the front panel.	front panel
6. Re	move the right-side panel	
	Remove the screw fixing the right-side panel, chassis, valve support and electric box. Remove the right-side panel.	right-side panel
7. Re	move the axial flow blade	
	Loosen the screw fixing the blade. Remove the axial flow blade.	axial flow blade

Step **Procedure** 8. Remove motor and motor support motor support Loosen the tapping screws fixing the motor. Disconnect the leading wire of motor. Remove the motor. Loosen the tapping screws fixing the motor support. Raise the support to remove it. 9. Remove electric box subassembly electric box subassembly Loosen the screws fixing the electric box subassembly. Loosen the binding line and disconnect the wiring terminal. Raise the electric box to remove it. 10. Remove isolation sheet Loosen the screws fixing the isolation isolation sheet sheet. Remove the isolation sheet. 11. Remove sound-proof sponge sound-proof Remove the sponge wrapping the compressor. sound-proof sponge

Step	Proc	edure
12. F	Remove magnetic coil Remove the screw of the magnetic coil. Remove the magnetic coil.	magnetic coil
13. R	emove valve support subassembly	
	Loosen the 2 bolts fixing the quick coupler. Solder off the quick connector, return air pipe and connecting pipe (capillary). Remove the valve support. (Note: discharge the refrigerant before soldering. Wrap the quick coupler with wet cloth to avoid damage from high temperature.)	valve support
14.	Remove compressor	4-way valve
а	Discharge the refrigerant. Solder off the pipe connecting the compressor (including 4-way valve, compressor, condenser, capillary.) Do not block the capillary during soldering.	capillary
b	Loosen the ground bolts fixing the compressor. Then remove the compressor.	compressor





GREE ELECTRIC APPLIANCES,INC.OF ZHUHAI

Add:Jinji west Rd.Qianshan Zhuhai Guangdong China

Tel:86-756-8522219 (After sale Service Dept)

Post code: 519070